


XIV) EXPLODED VIEWS





HOISTING & LIFTING

Work made easy.

Prod.Id	Description	Pos.
4491001	FAH/FBH-20-1 TOP HOOK ASS'Y	1
4491615	FAH/FBH-20-3/615 SAFETY LATCH 2T	3
4491105	FAH/FBH-20-11/105 TOP HOOK PIN	11
4491104	FAH/FBH-20-12/104 TOP HOOK STOPPER PIN	12
4491209	FAH/FBH-20-14/209 REINFORCING METAL	14
4490024	FAH/FBH/024 TANDWIELASET 2E+2E 1.0T	24
4491016	FAH/FBH-20-33 CHAIN WHEEL BOTTOM HOOK 2T	33
4491015	FAH/FBH-20-41/015 BOTTOM HOOK ASS'Y	41
4490049	FAH/FBH-10-049/146 4TH & 5TH GEAR ASS'Y	49
4490050	FAH/FBH-10-050/169 OPERATING ELEMENT A SET	50
4491626	FAH/FBH-20-58 IDLE WHEEL LOWER HOOK	58
4491072	FAH/FBH-72/604 BOLD FOR LOAD CHAIN 2T/3T	72
4490527	FAH/FBH-10-93/527 BALL BEARING	93
4490117	FAH/FBH-10-116 Plate spring 10 pieces	116
4490118	FAH/FBH-10-118 WASHER	118
4490119	FAH/FBH-10-119 NUT	119
4490133	FAH/FBH-10-133 MOTOR BRACKET	133
4490135	FAH/FBH-10-135/552 MOTOR STAY BOLT	135
4490524	FAH/FBH-10-140/524 MOTORSHAFT JOINT	141
4490401	FAH/FBH-10-152/401 LOAD SHEAVE	152
4490405	FAH/FBH-10-155/405 CHAIN GUIDE	155
4490420	FAH/FBH-CHAIN STRIPPER [IN 155]	155
4490409	FAH/FBH-10-161/409 ROLLER	161
4490412	FAH/FBH-10-163/412 SHEAVE COVER SET	163
4490438	FAH/FBH-10-166/438 HEX.SHAFT OPERATING ELEMENT	166
4490437	FAH/FBH-10-168/437 OPERATING PLATE	168
4490433	FAH/FBH-10-175/433 OPERATING ELEMENT A STOPPER	175
4490424	FAH/FBH-10-176/424 OPERATING ELEMENT B	176
4490016	FAH/FBH-10-177 LIMIT SWITCH	177
4490844	FAH/FBH-10-185/844 CHAIN BUCKET FITTING	185
4490843	FAH/FBH-10-189/843 CHAIN BUCKET HANGER FITTING	189
4490535	FAH/FBH-10-192/535 MAGN.BRAKE HOLDER SET	192
4490534	FAH/FBH-10-196/534 SQUARE HUB	196
4490562	FAH/FBH-10-197/562 BRAKE COIL	197
4490564	FAH/FBH-10-198/564 ARMATURE [A]	198
4490565	FAH/FBH-10-199/564 ARMATURE [B]	199
4490531	FAH/FBH-10-200/531 FRICTION DISCS	200/201
4490540	FAH/FBH-10-202/540 BRAKE SPRING	202
4490203	FAH/FBH-10-98 /203 STAY BOLT A	98
4490544	FAH/FBH-10-203/544 BOLT BRAKE	203
4490204	FAH/FBH-10-99/204 STAY BOLT B	99
4490543	FAH/FBH-10-204/543 BRAKE COVER	204
4490207	FAH/FBH-10-207/104 HANGER HOLDING	207



HOISTING & LIFTING

Work made easy.

4490209	FAH/FBH-10-209/14 BUSHING TOP HOOK	209
4491816	FAH/FBH-20-225 SPRING BOTTOM HOOK 150 MM	225
4490815	FAH/FBH-10-226/815B SWITCH SPRING	226
4490810	FAH/FBH-A-228/810 CHAIN STOPPER ASS'Y	228
4490236	FAH/FBH-10-236/121 GEAR CASE ASS'Y	236
4490238	FAH/FBH-10-238/83 BALL BEARING	238
4490241	FAH/FBH-10-241/84 BALL BEARING	241
4492025	FAH/FBH-A-243 FEMALE CONNECTOR 4 PINS	243
4492027	FAH/FBH-A-244 FEMALE CONNECTOR 6 PINS	244
4490657	FAH/FBH-A-246 CONTACTOR SUR 12 JY	246
4490248	FAH/FBH-10-248/208 PUSH BUTTON HANGER	248
4490651	FAH/FBH-A-250 TRANSFORMER 440V/24V	250
4490652	FAH/FBH-A-250 TRANSFORMER 400V/24V	250
4490252	FAH/FBH-10-252/134 BALL BEARING	252
4490599	FAH/FBH-A-252/599 ANTI-NEGATIVE PHASE DEVICE	252
4490253	FAH/FBH-10-253/223 MOTOR CASE PACKING	253
4490254	FAH/FBH-10-254/132 LOCATION PLATE	254
4490660	FAH/FBH-10-254/660 RECTIFIER	254
4492026	FAH/FBH-A-269 MALE CONNECTOR 4 PINS	269
4492113	FAH/FBH-A-275 CORD HOLDING FITMENT	275
4490301	FAH/FBH-10-301/141 1 ST GEAR SHAFT	301
4490307	FAH/FBH-10-307/149 6TH GEAR	307
4490312	FAH/FBH-10-312/125 BALL BEARING	312
4490313	FAH/FBH-10-313/85 BALL BEARING	313
4490321	FAH/FBH-10-321/86 BALL BEARING	321
4490322	FAH/FBH-10-322/126 BALL BEARING	322
4490323	FAH/FBH-10-323/124 BALL BEARING	323
4490325	FAH/FBH-10-323 FRICTION DISC FOR ROTOR !!! OLD TYPE!!	323
4490326	FAH/FBH-10-323 FRICTION DISC ROTOR NEW VERSION	323
4490324	FAH/FBH-10-324/127 GEAR CASE PACKING	324
4490361	FAH/FBH-10-361/205 ELECTRIC CASE	361
4490364	FAH/FBH-10-364/216 MOTOR SIDE CASE	364
4490658	FAH/FBH-755 MAGNETIC CONTACTOR EMERGENCY STOP	755
4491940	FAH-20-940 CAPACITY PLATE 2 TON	940
4492035	FAH/FBH-A-281/282 ELECTRIC PLUG METAL HOUSE COMPLETE	281-282
4491002	FAH/FBH-20-37/39/40/72 FITTINGSET FOR LOAD CHAIN	
4492031	FAH/FBH ONLY PIN MALE FOR PLUG	
4490791	FAH/FBH-A MOUNTING PLATE (A)	
4492028	FAH/FBH-A MALE CONNECTOR 6 PINS	
4492033	FAH/FBH ONLY PIN FEMALE FOR PLUG	